



You can express the thermal resistance of a 2-oz copper pc-board trace in degrees Celsius per watt, as a function of the trace area. This thickness of copper is typical of most pc boards.