



**Figure B** Noise-measurement instrumentation includes resistors, a closed-core current probe, a low-noise wideband amplifier, and an oscilloscope (a). A 10- $\mu$ A input pulse produces a calibrated and readily discernible output (b).