



Figure 5 Excessive damping trades off the rise time and rounds the front corner but minimizes pulse-top aberrations (a). Minimal damping accentuates rise time, but pulse-top ringing is excessive (b). Optimal damping retards pulse-top ringing and preserves rise time in the slew-rate-measurement region (c).