



Figure 1 Conventional solder pads offer two choices for Kelvin connections: on the pads' inner edges (a) or outer corners (b).