



Figure 2

A thermocouple monitoring a motor's stator temperature exemplifies applications in which small signal inputs are subject to large switching transients. Galvanic isolation eliminates common-mode terms.