



**Figure 3** You can assemble the probe on a piece of breadboard that fits into a section of brass tubing from model and hobby shops. An SMA input connector matches a multitude of adapters and probe tips, a few of which are shown. Use a rubber grommet to close the probe's output end.