



**Figure 12** In this higher gain version of Figure 11, spike amplitude measures 900  $\mu$ V—almost 20 times lower than without ferrite beads, whereas the instrumentation noise floor causes trace baseline thickening. (The trace center-screen area is intensified for photographic clarity.)

---