



Figure C A wideband, low-noise preamplifier permits submillivolt-spike observation. The coaxial connections must remain to preserve measurement integrity.