



Figure 2 To minimize the effects of high-frequency noise on sensitive analog circuits, you can convert the high-current PWM waveform applied to the fan to a continuous analog voltage.