



Figure F In good layout practice, the capacitor is in line with the current flow, creating a minimal loop size (a). Having the capacitor at right angles creates a large loop, causing ground bounce (b).