


(a)



(b)

Figure 4 Instead of a conventional connection (a), use a Kelvin connection (b) to ensure that no circulating or dc currents flow in the sensing trace running from the pads of a component.
