



Figure 6 The pc-board layout of the circuit in Figure 5 demonstrates good design practice that minimizes the effects of circulating currents.

---