



Figure 3 For best performance, place copper traces around the amplifier's high-impedance points to intercept leakage currents.