



Figure 1 Most harvesting applications rely on electronics that sporadically come to life, but a monitoring subsystem, such as this one, must continuously operate at ultralow-power levels, monitoring the energy store and awakening the processor to the task at hand when sufficient power is available.