



Figure 12 Trace A shows the crystal voltage, and Trace B shows the crystal current for the circuit in Figure 11. The 25- μ A rms-crystal-current measurement includes the 5- μ A noise-floor contribution of the preamplifier.
