



Figure 5 Trace A is the ac line of the SCR-based ac/dc converter. Trace B is the waveform at the SCR cathode. It contains dc and high-frequency harmonics that require wideband rms measurement to ensure accurate regulation.
