



Figure 1 The basic test setup for generating Bode plots requires a network analyzer, an analog oscilloscope with one or more vertical outputs, an optional dc-bias power supply, and a printer.