



Figure B Voltage and current noise is higher at low frequencies. The bend at which the voltage noise becomes horizontal is the $1/f$ corner. The horizontal section is flatband noise (courtesy Intersil).