



Figure D You can use an amplifier in an inverting configuration to measure current. The input-bias current of the pin creates a fundamental error that changes over time and temperature.