



Figure D Do-it-yourself Z_0 Probe 1 introduces pulse-corner rounding, likely due to resistor/cable parasitic terms or incomplete coaxiality. Probes of this type typically manifest this type of error at rise times of less than 2 nsec.
