



Figure 1 You can use an on-chip unused synchronous serial port to generate PWM signals and convert them to a slow-moving analog signal.