



Figure 2

Closing either pushbutton in Figure 1 increments the potentiometer's output in a direction that the MAX5161's U/D input indicates.