


Figure 4



The output load limits the current to V_{CLAMP}/R_L during a fault condition.