



Figure 2

To eliminate the resistive divider, you connect the ADC's reference voltage to its power supply and measure the precision voltage reference's output.