



Figure 2 The input structure of a SAR converter initially has a sample-and-hold capacitor, C_{SW} , following a switch, S_1 , which controls the sampling time.