



CONNECT REFERENCE
GROUND HERE.

Figure 7 Boost regulators have large circulating currents in the output capacitor and the switch ground. Do not put the reference ground between those nodes.